

Owner's Manual

DLP PROJECTOR

Please read this manual carefully before operating your projector and retain it for future reference.

PA70G

LICENSES

Supported licenses may differ by model. For more information about licenses, visit www.la.com.





Manufactured under license from Dolby Laboratories.

"Dolby "and the double-D symbol are trademarks of Dolby Laboratories.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. . This is an official DivX Certified® device that plays DivX video. Visit divx. com for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

"DivX Certified® to play DivX® video up to HD 1080p, including premium content."

"DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license."

"Covered by one or more of the following U.S. patents: 7,295,673; 7,460,668; 7,515,710; 7,519,274"



HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

This device meets the EMC requirements for home appliances (Class B) and is intended for home usage. This device can be used in all regions.



NOTE -

- Image shown may differ from your projector.
- Your projector's OSD (On Screen Display) may differ slightly from that shown in this manual.

SAFETY INSTRUCTIONS

Please take note of the safety instructions to prevent any potential accident or misuse of the projector.





The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING/CAUTION

- TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

FCC NOTICE

Warning - Class B

(b) For a Class B Digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.

Indoor Installation

WARNING

- Do not place the projector in direct sunlight or near heat sources such as radiators, fires, stoves, etc.
 - This may cause a fire.
- Do not place flammable materials such as aerosols near the projector.
 - This may cause a fire.
- Do not allow your children to cling to or climb up to the projector.
 - The projector may fall down and cause personal injury or death.
- Do not place the projector directly on a carpet, rug or place where ventilation is restricted such as a book shelf or closet.
 - This may cause the projector's internal temperature to rise and cause
- Do not place the projector close to sources of steam or oil such as a humidifier or kitchen counter.
 - This may cause a fire hazard or an electric shock.
- Do not place the projector where it might be exposed to excessive dust.
 - This may cause a fire.

- Do not use the projector in a damp place such as a bathroom where it is likely to get wet.
 - This may cause a fire or an electric shock.
- Do not allow a tablecloth or curtain to block the vents.
 - This may cause the internal temperature of the projector to rise and cause a fire.
- The distance between the projector and the wall should be more than 30 cm for ventilation purposes.
 - Otherwise, this may cause the internal temperature of the projector to rise and cause a fire.

↑ CAUTION

- · When installing the projector on a table, be careful not to place it near the edge.
 - The projector may fall causing injury to persons or damage to the projector. Make sure that you use a stand suitable for the size of projector.
- Turn off the projector, disconnect the power supply and remove all connec tions before moving the projector.
 - A damaged cord may cause a fire or an electric shock.
- Do not install the projector on an unstable or vibrating surface such as a vibrating shelf or tilted surface.
 - It may fall and cause injury.
- Be careful not to tip the projector over when connecting external devices to the projector.
 - This may cause injury to persons or damage to the projector.

Power

WARNING

- The earth wire should be connected.
 - Inappropriate earth grounding may cause damage to the projector or an electric shock when there is an electrical surge.

If the projector must be installed at a place where earth grounding is not possible, purchase a circuit breaker and connect the projector to its wall outlet.

Do not ground the projector to the gas pipe, water pipe, lightning rod, or telephone line, etc.

- The power plug should be fully inserted into the wall outlet.
 - Unstable connection may cause a
- Do not place heavy objects on the power cord or place the cord underneath the projector.
 - This may cause a fire or an electric shock.
- Never touch the power plug with a wet hand.
 - This may cause an electric shock.
- Do not connect too many devices to the same power extension.
 - Overheating may cause a fire.
- Remove dust or contaminants around power plug pins or wall outlets.
 - This may cause a fire.
- To turn off the main power, remove the power plug, which should be positioned so it is easy to access for operation.

A CAUTION

- Hold the plug firmly when unplugging.
 - A broken wire in the cord may cause a fire.
- Ensure the power cord or plug is not damaged, modified, severely bent, twisted, pulled, sandwiched or heated.
 Do not use a loose wall outlet.
 - This may cause a fire or an electric shock.
- Keep the power cord away from any heating devices.
 - The cord coating may melt and cause an electric shock.
- Place the projector where people will not trip over or tread on the power cord or plug to protect the power cord and plug from any damage.
 - This may cause a fire hazard or an electric shock.
- Do not turn the projector on or off by plugging in the power plug or unplugging it from the wall outlet.
 (Do not use the power plug as a switch.)
 - This may cause an electric shock or damage to the projector.
- Do not insert a conductor into the other side of the wall outlet while the power plug is inserted into the wall outlet.
 - In addition, do not touch the power plug immediately after it is disconnected from the wall outlet.
 - This may cause an electric shock.
- Use only the official power cord which is provided by LG Electronics, Inc. Do not use other power cords.
 - This may cause a fire or an electric shock.

When in Use

MARNING

- Do not place anything containing liquid, such as a vase, flowerpot, cup, cosmetics, chemicals, decorations or candles, etc., on top of the projector.
 - Possible fire, electric shock, or falling may cause physical injury.
- In the event that there is a big impact to the projector or the cabinet is damaged, switch it off, unplug it from the wall outlet and contact an authorized service center.
 - Otherwise, this may cause a fire or an electric shock.
- Do not insert pieces of metal such as coins, hairpins or metal debris, nor flammable materials such as paper or matches into the projector.
 - This may cause a fire or an electric shock
- In the event that liquid or a foreign object falls into the projector, please switch it off and unplug it from the wall outlet and contact an LG Electronics Service Center.
 - Otherwise, this may cause a fire or an electric shock.
- When replacing a battery of the remote control, make sure a child does not swallow the battery. Keep the battery out of reach of children.
 - In the case of a battery being swallowed by a child, please consult a doctor immediately.
- Do not remove any covers except for the lens cap. There is a high risk of electric shock
- Do not look directly into the lens when the projector is in use. The strong light may damage your eyes.

- When the lamp is on or has just been turned off, avoid touching the air vent or lamp because these will be very hot.
- If there is a gas leak, do not touch the wall outlet. Open the window for ventilation.
 - A spark may cause a fire or burn.
- Always open the lens door and remove the lens cap when the projector lamp is on.
- Never touch the projector or power cord during thunder or lightning.
 - This may cause an electric shock.
- Do not use the projector near an electronic device which generates a strong magnetic field.
- Store the vinyl envelope used to pack the projector in a safe place away from children.
 - It could cause suffocation if used improperly.
- Do not use 3D glasses if you do not watch 3D.
- Do not keep your hand on the projector for a long time when it is running.
- When you play a game by connecting a game console to a projector, it is recommended that you maintain a distance of more than four times the diagonal length of the screen.
- Make sure that the length of connecting cable is long enough.
 Otherwise, the product may fall causing personal injury or damage to the product.

A CAUTION

- Do not place a heavy object on the projector.
 - It may fall down and cause physical injury.
- Be careful to prevent the lens from heavy impact during transportation.
- Do not touch the lens.
 The lens may be damaged.
- Do not use any sharp tools on the projector such as a knife or hammer, because this may damage the casing.
- In the event that no image appears on the screen, switch the projector off, unplug it from the wall outlet and contact an authorized service center.
 - Otherwise, this may cause a fire or an electric shock.
- Do not drop an object onto the projector or apply heavy pressure to it.
 - This may cause injury to persons or damage to the projector.
- The distance between your eyes and the screen must be around 5 -7 times the diagonal length of the screen.
 - If you watch the screen at a close distance for a long time, your eye sight may become worse.

Cleaning

▲ WARNING

- Do not spray the projector with water when cleaning. Do not allow water to go into the projector or do not allow it to get wet.
 - This may cause a fire or an electric shock.
- When there is smoke or a strange smell coming out from the projector or a foreign object falls into the projector, please switch it off and unplug it from the power outlet and contact an LG Electronics Service Center.
 - If not, this may cause a fire or an electric shock.
- Use an air spray or soft cloth or cotton swab moistened with a lens cleaning chemical or alcohol to remove dust or stains on the front projection lens.

⚠ CAUTION

- Contact your seller or the Service
 Center once a year to clean the internal parts of the projector.
 - If you do not clean the contaminated interior of the projector for a long time, there may be a fire or damage to the projector.
- When cleaning plastic parts such as the projector case, unplug the power first and wipe with a soft cloth. Do not spray with water or wipe with a wet cloth. When cleaning the plastic parts, such as the projector case, do not use cleanser, automobile or industrial shiner, abrasive or wax, benzene, alcohol, etc., which can damage the product.
 - This can cause fire, electric shock or product damage (deformation, corrosion and damage).

OTHERS

WARNING

- Only a qualified technician can disassemble or modify the projector. For inspection, adjustment, or repair, contact your seller or the Service Center.
 - Otherwise, this may cause a fire or an electric shock.
- Do not charge the battery using any devices other than the one provided with the product.
 - This may result in damage to the battery or fire.
- · Dispose of the used battery properly.
 - Otherwise, this may result in explosion or fire.
- The correct method of disposal may vary depending on your country or region. Dispose of the battery pack according to the appropriate instructions.
- Do not throw or disassemble the battery.
 - -Otherwise, this may result in fire or explosion due to damage to the battery.
- Always use batteries approved and certified by LG Electronics.
 - Otherwise, this may result in fire or explosion.
- Store the battery away from metallic objects, such as keys and paper clips.
- Excess current may cause a rapid increase in temperature, resulting in fire or burns.
- Do not store the battery near any heat source, such as a heater.
 - This may result in fire or damage the product.

- Do not store it at temperatures higher than 60°C or in high humidity.
- Keep the battery out of reach of children.
 - This may result in personal injury or damage to the product.
- Make sure that the battery is installed correctly.
- The battery contains lithium-ion, so please handle with care.
- Make sure you use the same type of battery for replacement.
- Incorrect battery replacement may cause fire

A CAUTION

- Do not mix new batteries with old batteries.
 - This may cause a fire or an electric shock caused by overheating and leakage.
- Unplug the power cord if the projector is not used for a long period.
 - Accumulated dust may cause overheating, an electric shock from corroded insulation and a fire from an electrical surge.
- Only use the specified type of battery.
 - Otherwise, this may cause an electric shock caused by overheating and leakage.

Contents

- MUSIC LIST

- FILE LIST

LICENSES	2	3D FUNCTION	38
		Before Watching 3D	38
SAFETY INSTRUCTIONS	3	- While Watching 3D	38
		Requirements for Watching 3D Im-	ages
PREPARATION	11		40
Accessories	11	 To Use DLP-LINK (DLP-Ready) 	Туре
Optional Extras	12	Glasses	42
Parts and Components	13	Watching 3D Images	42
Installation	14	CUSTON WITH A SETTINGS	40
- Installation Precautions	14	CUSTOMIZING SETTINGS	43
- Projection Distance per Screer	n Size	SETUP Menu	43
	15	PICTURE Settings	44
- How to Install the Projector Us	ing a	AUDIO Settings	48
Tripod	16	TIME Settings	49
- Kensington Security System	16	OPTION Settings	50
REMOTE CONTROL	17	MAKING CONNECTIONS	52
		Connecting to an HD Receiver, DV	D, or
USING THE PROJECTOR	19	VCR Player	53
Watching Projector	19	- HDMI Connection	53
- Turning on the Projector	19	Connecting to a PC	53
- Focus and Position of the Scre	en	- RGB Connection	53
Image	19	Connecting to the AV INPUT	54
- Watching Projector	19	- Component Connection	55
Using Additional Options	20	Connecting to	
- Adjusting Aspect Ratio	20	Headphones	55
- Using the Keystone		MAINTENANCE	E 6
Function	21		56
- Using the Input List	21	Cleaning the Projector	56
- Blank Function	22	- Cleaning the Lens	56
Using the Quick Menu	22	- Cleaning the Projector Case	56
ENTERTAINMENT	23	How to Fix the Lens Cap	56
MY MEDIA	23	SPECIFICATIONS	57
- Connecting USB Storage Devi			
- MOVIE LIST	25		
- PHOTO LIST	32		


34 36

PREPARATION


Accessories

Check enclosed accessories.

The picture may be different from an actual product.




 When connecting a cable to the HDMI or USB port, it may not be connected properly if the size of jack to the USB/HDMI port is too big. Use a standard sized jack.



Optional Extras


To purchase optional extras, visit an electronics store or online shopping site or contact the retail store where you purchased the product.

Without prior notice, optional extras are subject to change in order to improve the performance of the product, and new accessories may be added.



Parts and Components

* The projector is manufactured using high-precision technology. You may, however, see tiny black dots and/or bright colored dots (red, blue or green) that continuously appear on the projector screen. This is a normal result of the manufacturing process and does not indicate a malfunction.



Button	Description	
⊚ (Power)	Turns the projector on or off.	
(Menu) (Menu)	Selects or closes menus.	
VOL -, +	Adjusts the volume level.	
∧, ∨, <,>	Sets the function or moves the cursor.	
⊚ (OK)	Checks present mode and saves function changes.	

- 1 Due to the high temperature air coming out of the vents, do not get close to the vents.
- 2 Do not touch the lens when using the projector or opening the lens cap. The lens may be damaged.

Installation

Installation Precautions

- Place the projector in a well-ventilated environment.
- To prevent internal heat from building up, install the projector in a wellventilated place.
 - Do not place anything near the projector as this may block its air vents. If the air vents are blocked, the internal temperature will increase.



 Do not place the projector on a carpet or rug. If a projector model has its inlet vent on its bottom, do not block the vent and use the projector on a leveled solid surface



 Be sure to prevent foreign objects such as paper debris from entering the projector.




- Leave an adequate distance (30 cm or more) around the projector.



- Do not place the projector in a hot or humid environment.
 - Do not place the projector in a hot, cold, or humid environment. (See 57 Page regarding operating temperature and humidity.)
- Do not place the projector in a place where it will easily attract dust.
 - This may cause a fire.
- Do not remove any covers except for the lens cap. There is a high risk of electric shock.
- The projector is manufactured using high-precision technology. You may, however, see tiny black dots and/ or bright colored dots (red, blue or green) that continuously appear on the projector screen. This is a normal result of the manufacturing process and does not indicate a malfunction.
- The remote control may not work in an environment where a lamp equipped with electronic ballasts or a three-wavelength fluorescent lamp is installed. Replace the lamp with an internationally standardized lamp for the remote control to work normally.

Projection Distance per Screen Size


- 1 Place the projector on a sturdy, level surface, together with the PC or audio/video source.
- **2** Place the projector at an appropriate distance from the screen. The distance between the projector and the screen determines the actual size of the image.
- 3 Position the projector so that the lens is set at a right angle to the screen. If the projector is not set at a right angle, the image on the screen will be tilted and the image quality will be poor. If the screen image is crooked, use the Keystone function. (see page21)
- 4 Connect the power cords of the projector and the connected devices to the wall outlet.



	16:10 Screen		
Screen Size (mm)	Screen Width (Y) (mm)	Screen Height (X) (mm)	Projection Distance (D) (mm)
762	646	404	902
889	754	471	1056
1016	861	539	1210
1143	969	606	1365
1270	1077	673	1520
1397	1185	741	1674
1524	1292	808	1828
1651	1400	875	1983
1778	1508	943	2137
1905	1615	1010	2291
2032	1723	1077	2445
2159	1831	1145	2600
2286	1938	1212	2755
2413	2046	1279	2909
2540	2154	1347	3063

How to Install the Projector Using a Tripod


- You can install this projector using a camera tripod.
 As shown below, you can mount the projector instead of a camera on the tripod.
- When stabilizing the tripod, we recommend using the locking bolt of standard size 4.5 mm or less. The maximum size allowed for the locking bolt is 5.5 mm. (If it is longer than the maximum allowed size, it may damage the projector.)



Kensington Security System

- This projector has a Kensington Security System Connector on the panel. Connect a Kensington Security System cable as below.
- For detailed installation and use of the Kensington Security System, refer to the user's guide included with the Kensington Security System set.
- The Kensington Security System is an optional item.
- What is Kensington?

 Kensington is a company that sells security systems that prevent expensive electronic equipment such as a computer or laptop from being stolen.



REMOTE CONTROL


Open the battery cover on the back of the remote control and insert the specified batteries as per instructions Θ . The same type of batteries (1.5 V AAA) must be used. These must also be new batteries.






CAUTION -

· Do not mix a new battery with an old battery.








NOTF-

When using the remote control, the optimal remote range is less than 6 meters (left/right) and within a 30 degree arc of the IR receiver.



- For seamless operation, do not block the IR receiver.
- When you carry the remote control in the portable bag, make sure that the buttons
 on the remote control are not pressed by the projector, cables, documents or any
 other accessories in the bag. Otherwise, it may significantly reduce the battery life.





Using the PROJECTOR

Watching Projector

Turning on the Projector

- 1 Connect the power cord correctly.
 - Check if the lens cap is open before turning on the projector.
- 2 After waiting for a moment, press the **POWER** button on the remote control or the control panel. (The light on the control panel will be turned on.)
- 3 In the Language Selection screen, select a language.
- 4 Select an input signal by using the **INPUT** button on the remote control.

Focus and Position of the Screen Image

When an image appears on the screen, check if it is in focus and fits the screen properly.



• To adjust the focus of the image, rotate the focus ring.

Watching Projector

- 1 In Standby mode, press the **POWER** button to turn the projector on.
- 2 Press the **INPUT** button and select the input signal you want.
- 3 Control the projector using the following buttons while watching projector.

Button	Description	
VOL -, +	Adjusts the volume level.	
MUTE	Mutes all sounds.	
Q.MENU	Accesses the quick menu. (see page22)	
	(see pagezz)	
RATIO	Resizes an image.	
Key's ▲ ,▼	Adjusts Keystone. (see	
	page21)	

4 To turn the projector off, press the **POWER** button.

Using Additional Options

Adjusting Aspect Ratio

Resize an image to view at its optimal size by pressing **RATIO** while you are using the projector.



NOTE

- Some options may not be available depending on input signals.
- You can also change the image size by pressing Q.MENU or SETTINGS.
- FULL: Changes to the full screen regardless of the aspect ratio.



 16:9: Resizes images to fit the screen width.



 Just Scan: Displays video images in the original size without cutting off the edges.





NOTE

- If you select Just Scan, you may see image noises at the edge or edges of the screen.
- Set By Program: Displays images in the same aspect ratio as the original image.



4:3: Resizes images to the 4:3 aspect ratio.



- Zoom: Enlarges an image to fit the screen width. The top and bottom of the image may be truncated.
 - Press the < or > button to zoom in or out of the image.
 - Press the \(\rangle \) or \(\rangle \) button to move the image.



- Cinema Zoom: Formats an image to the cinemascope ratio, 2.35:1. It ranges from 1 to 16.
 - Press the < or > button to zoom in or out of the image.
- Press the \(\rightarrow\) or \(\rightarrow\) button to move the image.





NOTE

• If you enlarge or reduce an image, the image may be distorted.

<u>Using the Keystone</u> Function

To prevent the screen image from becoming trapezoidal, Keystone adjusts the top and bottom width of the image if the projector is not set at a right angle to the screen.

Because the **Keystone** function may cause inferior screen image quality, use this function only when it is not possible to set up the projector at an optimal angle.




- Press the Key's A or Key's V button to adjust the screen.
 - Keystone can be adjusted from -40 to 40
- Press the **OK** button after adjustment.

Using the Input List

Using the Input List


- Press the **INPUT** button to access the input sources.
 - The connected input mode appears first. However, AV / Component input is always activated.



2 Select an input signal using the INPUT button and the projector is switched only to the connected input mode. You can use the ∧, ∨, < or > button to switch between all the input modes.

Adding an Input Label

Displays which devices are connected to which input ports.



- 1 Press the **INPUT** button to access the input sources.
- 2 Press the **BLUE** button.
- 3 Use the ∧ or ∨ button to scroll to one of the input sources.
- 4 Use the < or > button to select one of the input labels.

Blank Function

Using the Blank Function

This function may be effective when you need to draw attention during a meeting or training.

- Press the **BLANK** button, and the screen is covered by the background color.
 - You can change the background color by referring to "Selecting a Blank Image".
- 2 Press any button to clear the blank function.

To cover the screen temporarily, press the **BLANK** button on the remote control

Do not block the lens with any object while the projector is running.

It may become overheated and deformed or even cause a fire.

Selecting a Blank Image

- 1 Press the **SETTINGS** button.
- 2 Press the ∧, ∨, < or > button to select **OPTION** and press the **OK** button.
- 3 Press the ∧, ∨, < or > button to select **Blank Image** and press the **OK** button.
- **4** Use the ∧, ∨ button to move to the setting or option you want and press the **OK** button.

Using the Quick Menu

You can customize frequently used menus.

- 1 Press Q.MENU to access the quick menus
- 2 Press the < or > button to scroll through the following menus and press **OK**.

Menu	Description
Aspect	Resizes an image.
Ratio	(see page20)
Picture	Changes the picture
Mode	mode. (see page44)
Energy	Adjusts brightness.
Saving	
Clear	Makes the voice from the
Voice II	projector crisp and clear.
Sound	Set each option as de-
Mode	sired.
Sleep	The projector is turned off
Timer	at the preset time.
PJT Mode	Turns the projected image
	upside down or flips it
	horizontally.
USB	Disconnects a USB de-
Device	vice.

3 Press the \land , \lor , \lt , or \gt button to scroll through the following menus.

ENTERTAINMENT

MY MEDIA

Connecting USB Storage Devices

Connect a USB memory stick as shown below.

When a USB storage device is connected, the USB adjustment screen appears. You cannot write or delete data on the USB storage device.



To disconnect the USB storage device,

- 1 Press the **Q.MENU** button.
- 2 Use the < or > button to move to USB Device and press the OK button.
- 3 Remove the USB device.



NOTE

 After the USB storage device is disconnected, it cannot be read.
 Remove the USB storage device and connect it again.

Tips for Using USB Devices

- Only a USB storage device is recognizable.
- USB hubs are not supported.
- A USB storage device which uses its own driver may not be recognized.
- The recognition speed of a USB storage device will depend on each device.
- If a normal USB device does not work, disconnect and reconnect it.
 Please do not turn off the projector or unplug the USB device when the connected USB device is working.
 The USB device or stored files may be damaged.
- Please do not connect the USB storage device that has been manipulated on the PC. The projector may not operate properly or fail to play files. Use a USB storage device which contains normal music, photo, video, or document files.
- Please only use a USB storage device formatted as a FAT16, FAT32, or NTFS file system provided by Windows. In case a storage device formatted as a different utility program is not supported by Windows, it may not be recognized.
- Please connect power to a USB storage device which requires an external power supply. If not, the device may not be recognized.

- Please connect a USB storage device with a cable provided by the USB manufacturer. When you use a cable that is not provided by a USB manufacturer or an excessively long cable, the device may not be recognized.
- Some USB devices may not be supported or will not work properly.
- If the length of a folder or file is too long, the folder or file may not be recognized properly.
- The files in a USB storage device are sorted in the same way as Windows XP. Up to 100 English characters for a file name are allowed.
- The data of a USB device may be damaged, so it is recommended to backup any important files. Because a user is responsible for data management, the manufacturer is not responsible.
- It is recommended to use a USB memory stick which is 32 GB or less and a USB hard disk which is 1 TB or less. Any device with more than the recommended capacity may not work properly.
- If a USB storage device is not working properly, disconnect it and connect it again.
- If a USB external hard disk with the power saving function does not work, turn the hard disk off and on again to make it work properly.
- USB storage devices below USB 2.0
 are supported as well. However, they
 may not work properly in the movie
 list.

MOVIE LIST

In the Movie List, you can watch movies stored on the connected USB device.

Tips for Playing Video Files

- Some subtitles created by a user may not work.
- Some special characters are not supported in subtitles.
- HTML tags are not supported in subtitles.
- Time information in a subtitle file should be arranged in ascending order to play the subtitle properly.
- Changing font and color in subtitles is not supported.
- A language which is not specified in the subtitle languages is not supported. (see page30)
- Subtitle files of 1 MB or larger are not supported.
- The screen may suffer temporary interruptions (image stoppage, faster playback, etc.) when the audio language is changed.
- A damaged video file may not be played properly, or some functions may not be available.
- Video files created with some encoders may not be played properly.
- Either audio or video may only be supported depending on the video or audio packet structure of a video file.
- Video files with higher resolution than the maximum supported for each frame may not be played properly.
- Video files in formats other than the ones specified above may not be played properly.

- Streaming files which include GMC (Global Motion Compensation) or Qpel (Quarterpel Motion Estimation) is not supported.
- Up to 10,000 sync blocks are supported in the subtitle file.
- Seamless playback is not guaranteed for files encoded level 4.1 or higher in H.264/AVC.
- DTS audio codec is not supported.
- Video files larger than 30 GB (Gigabytes) are not supported.
- Playing a video via a USB connection that does not support high speed may not work properly.
- A video file and its subtitle file must be located in the same folder. A video file name and its subtitle file name must be identical in order to display the subtitle properly.
- While watching a video using the movie list function, you cannot adjust the picture mode.
- Trick Mode does not support other functions than if video files do not have index information.
- When playing a video file using network, the Trick mode is limited to 2X speed.
- Video file names that contain special characters may not be playable.

Supported Video Formats

File Extensions	Audio/ Video	Codec	Profile/Level Support
	Video	VC-1 Advanced Profile	Advanced Profile @ Level 3 (e.g.720p60,1080i60,1080p30) Only streams compliant to SMPTE 421M VC-1 standard are supported.
.asf .wmv		VC-1 Simple and Main Profiles	Simple Profile @ Medium Level (e.g.CIF,QVGA) Main Profile @ High Level (e.g.1080p30) Only streams compliant to SMPTE 421M VC-1 standard are supported.
	Audio	WMA Standard	
	Audio	WMA 9 Professional	
		Divx3.11	
	Video	Divx4 Divx5 Divx6	Advanced Simple Profile(720p/1080i)
		XViD	Advanced Simple Profile(720p/1080i)
.divx .avi		MPEG-1 Layer I,II	
.dVI		MPEG-1 Layer III (MP3)	
	A !! .	Dolby Digital	
	Audio	WMA Standard	
		WMA 9 Professional	
		DTS	Korea only
.mp4	Video	H.264 /AVC	Main Profile @Level 4.1 High Profile @Level 4.1 (e.g.720p60,1080i60,1080p30)
.m4v		MPEG-4 Part 2	Advanced Simple Profile(720p/1080i)
	Audio	HE-AAC	HE-AAC-LC and HE-AAC
	Video	H.264 /AVC	Main Profile @Level 4.1 High Profile @Level 4.1 (e.g.720p60,1080i60,1080p30)
.mkv		HE-AAC	HE-AAC-LC and HE-AAC
	Audio	Dolby Digital	
		DTS	Korea only
	Video	H.264 /AVC	Main Profile @Level 4.1 High Profile @Level 4.1 (e.g.720p60,1080i60,1080p30)
.ts		MPEG-2	Main Profile @High Level (e.g.720p60,1080i60)
.trp		MPEG-1 Layer I,II	
.tp		MPEG-1 Layer III (MP3)	
	Audio	Dolby Digital	
		HE-AAC	HE-AAC-LC and HE-AAC
	Video	MPEG-1	
		MPEG-2	Main Profile @High Level (e.g.720p60,1080i60)
.vob	Audio	Dolby Digital	
		LPCM	
		MPEG-1 Layer I,II	
.mpg	Video	MPEG-1	
.mpeg .mpe	Audio	MPEG-1 Layer I,II	Only streams compliant configured properly for TS, PS or ES


Supported Audio Files

No	Audio Codec	Bit rate	Sampling rate	Remark
1	мР3	32kbps ~ 320kbps	32kHz ~ 48kHz	
2	AC3	32kbps ~ 640kbps	32kHz, 44.1kHz, 48kHz	
3	MPEG	32kbps ~ 448kbps	32kHz ~ 48kHz	
4	AAC,HEAAC	24kbps ~ 3844kbps	8kHz ~ 96kHz	DTS Audio codec is Korea only.
5	CDDA	1.44kbps	44.1kHz	
6	LPCM	1.41Mbps ~ 9.6Mbps	Multi-channel : 44.1 kHz,88.2kHz / 48 kHz, 96kHz Stereo : 176.4kHz, 192kHz	

Browsing Movie List

Play a video file stored in the connected device.

- 1 Connect a USB storage device.
- 2 Press the USB button.
- **3** Use the ∧, ∨, < or > button to select **Movie List** and press the **OK** button.
- **4** Use the ∧, ∨, < or > button to select the file you want and press the **OK** button.



Description	1
Thumbnails	
Abnormal file	5 ×
File not supported	5
File List	
Moves to the upper le	vel folder.
Current page/Total no. of folder	
pages	
Current page/Total no	. of file
pages	
Moves to the top level	folder.
Moves to the upper le	vel folder.
Exit Movie List.	
	Abnormal file File not supported File List Moves to the upper level Current page/Total not pages Current page/Total not pages Moves to the top level Moves to the upper level

5 Control playback by using the following buttons.



Setting	Description
♦ ▶	Shows the current playing
	position. Use $<$, $>$ buttons to
	move forward or backward.
	Stops playing and returns to
	Movie List.
•	Returns to normal playback.
Ш	Pauses the media player.
	If no button is pressed on the
	remote control for 10 minutes
	after pausing, the playback is
	restarted.
	■ Displays in slow motion.
«»	Whenever this button is
	pressed, the playback speed
	is changed.
	: x2, x4, x8, x16, x32
	You can use the Energy
eØ	Saving mode.
Ontion	A non un window will appear
Option	A pop-up window will appear.
Hide	Hides the playback bar. Press
	the OK button to make it
	appear.
Exit	Returns to the Movie List
	screen.

Options for Movie List

- 1 Press the **Q.MENU** button.
- 2 Use the ∧ or ∨ button to move to a desired option and press the OK button.
- **3** Use \land , \lor , < or > button to set up each item.

Set Video Play

Setting	Description
Picture	Selects the size of a playback
Size	 screen. Full: Files are played in full screen mode according to the aspect ratio of video. 16:9: Displays the video with the aspect ratio of 16:9. Just Scan: Displays the video in the original aspect ratio.
Audio Lan- guage	Allows you to select the language you want for the file with multiple audio tracks. This option is not available if the file has only one audio track.
Subtitle Lan- guage	The subtitle can be turned on or off. • Language: One of any of the available languages can be selected. • Code Page: A character set used for a subtitle can be selected. By default, the subtitle is displayed in a language configured in OPTION → Menu Language.

Setting	Description	
Subtitle	Speed: If a subtitle is	
Lan-	not synchronized with its	
guage	video, you can adjust its	
	speed at 0.5 sec unit.	
	Position: Moves the loca-	
	tion of a subtitle.	
	Size: Changes the sub-	
	title font size.	
Repeat	Turns the repeat function on	
	or off.	
	When it is set to off, the next	
	file can be played sequentially	
	if the file name is similar.	

Subtitle Language

Subtitle	
Lan-	Language
guage	
Latin1	English, Spanish, French,
	German, Italian, Swedish,
	Finnish, Dutch, Portuguese,
	Danish, Romanian,
	Norwegian, Albanian,
	Gaelic, Welsh, Irish, Catalan,
	Valencian
Latin2	Bosnian, Polish, Croatian,
	Czech, Slovak, Slovenian,
	Serbian, Hungarian
Latin4	Estonian, Latvian, Lithuanian
Cyrillic	Bulgarian, Macedonian,
	Russian, Ukranian, Kazakh
Greek	Greek
Turkish	Turkish
Hebrew	Modern Hebrew
Chinese	Simplified Chinese
Korean	Korean
Arabic	Arabic

PICTURE Settings

You can change video settings. (Refer to "PICTURE Settings" on page 44.)

AUDIO Settings

You can change audio settings. (Refer to "AUDIO Settings" on page 48.)

Registering the DivX code

Please check your DivX code. For more information on the registration process, visit www.divx.com/vod. After registration, your can enjoy DivX VOD content protected by the DivX DRM code.

1 In the Home menu, move to **OPTION** and press **DivX(R) VOD**.



2 Press the ∧ or ∨ button to move to **Registration** and press the **OK** button.



3 Check the DivX registration code.



- You cannot use DivX registration codes assigned to other devices.
 Make sure to use the DivX registration code assigned to your device.
- The video or audio files that are not converted by the standard DivX codec may be corrupted or not be played.

To deregister the DivX code

Use the DivX deregistration code to deactivate the DivX DRM function.

- 1 In the Home menu, move to **OPTION** and press **DivX(R) VOD**.
- 2 Use the ∧ or ∨ button to go to Deregistration and press the OK button.



3 Select Yes.

Yes



What is DRM
 [Digital Rights Management]?
 This is a technology and service that prevents the illegal use of digital contents to protect the benefits and rights of the copyright owner. Files can be played after the license is verified through an online method, etc.

PHOTO LIST

You can see the photos stored on a connected device.

Supported Photo Files

PHOTO (*.JPEG)

Baseline: 64-pixel (width) x 64-pixel (height) - 15360-pixel (width) x


8640-pixel (height)

Progressive: 64-pixel (width) x 64-pixel (height) - 1920-pixel (width) x 1440-pixel (height)

- Only JPEG files are supported.
- Non-supported files are displayed in the form of an icon.
- An error message is displayed for corrupted files or file formats that cannot be played.
- Corrupted files may not be displayed properly.
- It may take some time to view highresolution images in full screen.

Browsing Photo List

- 1 Connect a **USB storage device**.
- 2 Press the USB button.
- 3 Use the ∧, √, < or > button to select **Photo List** and press the **OK** button.
- 4 Use the ∧, √, < or > button to select the file you want and press the OK button.



	Description
0	Thumbnails
	Abnormal file
	File not supported
2	File List
8	Moves to the upper level folder.
4	Current page/Total no. of folder
	pages
6	Current page/Total no. of file
	pages
6	Moves to the top level folder.
0	Moves to the upper level folder.
8	Exit

Control playback by using the following buttons.



Setting	Description
00	Selects the previous or next
	photo.
Slide-	All photos are displayed
show	during slide show.
	Set the time interval of
	the slide show in Option
	→ Set Photo View menu.
BGM	You can listen to music while
	viewing photos in full size.
	Set the BGM in Option
	→ Set Photo View menu.
υ	Rotates photos. Rotates a photo 90°, 180°, 270°, 360° clock- wise. Photos cannot be rotated if their width is greater than the height of the max. supported resolu- tion.
Q	Views the photo in full mode or original mode.
	Press the blue button to enlarge the image.
eØ	You can use the Energy Sav-
	ing mode.
Option	A pop-up window will ap-
	pear.

Setting	Description
Hide	Hides the menu on the full
	size screen.
	 To see the menu, press
	the OK button on the
	remote control.
Exit	Exit from full screen photo
	view.

Options for Photo List

- 1 Press the **Q.MENU** button.
- 2 Use the ∧ or ∨ button to move to a desired option and press the OK button.
- 3 Use \land , \lor , \lt or \gt button to set up each item.

Set Photo View

Setting	Description
Slide	Selects a slideshow speed.
speed	
BGM	Selects a music folder for
(Back-	the background music.
ground	 You cannot change the
Music)	music folder while the
	background music is
	playing.
	 For background music,
	only the folder from the
	same device can be se-
	lected.

PICTURE Settings

You can change video settings. (Refer to "PICTURE Settings" on page 44.)

AUDIO Settings

You can change audio settings. (Refer to "AUDIO Settings" on page 48.)

MUSIC LIST

You can play audio files stored on the connected device.

Supported Music Files


*.MP3

Bit rate range 32 Kbps - 320 Kbps

- Sampling rate MPEG1 Layer3: 32kHz, 44.1kHz, 48kHz
- Sampling rate MPEG2 Layer3: 16kHz, 22.05kHz, 24kHz

Browsing Music List

- 1 Connect a **USB storage device**.
- 2 Press the **USB** button.
- 3 Use the \land , \lor , \lt , \gt button to select **Music List** and press the **OK** button.
- **4** Use the ∧, ∨, < or > button to select the file you want and press the **OK** button.



	Description	
0	Thumbnails	
	Abnormal file	
	File not supported	×
2	File List	
8	Moves to the upper leve	el folder.
4	Current page/Total no.	of folder
	pages	
6	Current page/Total no.	of file
	pages	
6	Moves to the top level f	older.
0	Moves to the upper leve	el folder.
8	Exit	

5 Control playback by using the following buttons.



Setting	Description
4	Changes the playing position.
	Stops playing.
•	Returns to normal playback.
II	Pauses the media player.
4 >	Plays the previous/next file.
eØ	You can use the Energy Sav-
	ing mode.
Option	Sets up the options of Music
	List.

Setting	Description
Hide	Hides the playback bar.
	Press the OK button to
	make the playback bar
	appear.
Exit	Returns to the Music List
	screen.

Options for Music List

- 1 Press the **Q.MENU** button.
- 2 Use the ∧ or ∨ button to move to a desired option and press the **OK** button.
- 3 Use \land , \lor , \lt or \gt button to set up each item.

Set Audio Play

Setting	Description
Repeat	Selects repeat play.
Random	Selects random play.

AUDIO Settings

You can change audio settings. (Refer to "AUDIO Settings" on page 48.)

FILE LIST

You can see document files stored on a connected device.

Supported File Formats


XLS, DOC, PPT, TXT, XLSX, PPTX, DOCX, PDF,

Microsoft Office 97/2000/2002/2003/2007 Adobe PDF 1.0/1.1/1.2/1.3/ 1.4

- File Viewer realigns a document, so it may look different from what is displayed on a PC.
- For documents that include images, the resolution may look lower during the realigning process.
- If the document volume is big or it has many pages, it may take longer to load the document.
- Unsupported fonts may be replaced by other fonts.

Browsing File List

- 1 Connect a **USB storage device.**
- 2 Press the **USB** button.
- 3 Use the ∧, √, < or > button to select **File List** and press the **OK** button.
- 4 Use the ∧, ∨, < or > button to select the file you want and press the OK button.



	Description
0	File List
2	Moves to the upper level folder.
3	Current page/Total no. of folder
	pages
4	Current page/Total no. of file
	pages
6	Moves to the top level folder.
6	Moves to the upper level folder.
0	Exit

- **5** Control playback by using the following buttons.
 - Click Go Page then the pop-up window for selecting the number of page appears.
 - Input the page to move to the page vou want.
 - Press the volume button to zoom in or zoom out.
 - 1. Press OK.
 - 2. Press the Up/Down/Left/Right buttons to move to Go Page or Zoom.



Setting	Description
Go	Moves to the page you want.
Page	Use the Up/Down/Left/Right buttons to select a page and press the OK button.
Zoom	Views the photo in full mode or original mode.
Option	Sets up the options of File
	Viewer.
Hide	Hides the menu. • Press the SETTINGS but-
	ton to make it appear.
Exit	Returns to the File Viewer
	screen.

Set FileViewer Option

Setting		Description
Single Page Loading	On	Loads and displays pages one by one. The initial loading time is short but a content- heavy page may be displayed slowly.
	Off	Loads all pages of a file to memory before it starts to display them. The initial loading time is long but you can navigate pages quickly after loading is complete. If a file is too large, it may fail to load all the pages.
Image Quality	the ir docu three for th Medi imag	can set the quality of mage included in the ment. The following coptions are available the image quality: High, um, Low. Higher the quality, lower the ay time.
Docu- ment Align		ets initial document method.

File View settings are default, so close the currently opened document to apply changes to the new document, if any.

3D FUNCTION

3D technology uses different video frames for each eye to add depth to the video.

Before Watching 3D

While Watching 3D

WARNING

- If you view 3D images too closely for a long period of time, it may cause blurred vision.
- If you watch the projector or game screen for a long time with 3D glasses on, you may experience dizziness or eye fatigue.
- If you are pregnant, a senior citizen, intoxicated, have heart problems, or easily feel motion sickness, we recommend that you do not watch 3D images.
- Because 3D images can be recognized as real, some viewers may get surprised or overexcited.
- Do not watch 3D images near fragile objects or any objects that can be knocked over easily.
- Take care not to injure yourself as you may subconsciously try to move away from the life-like 3D images.
- Prevent children of 5 years or younger from watching a 3D video. It may impair the development of their eyes.

Warning about photosensitivity seizures

- Some users may experience a seizure or other abnormal symptoms when they are exposed to a flashing light or particular pattern from a video game or movie. If anyone in your family has a history of epilepsy or has ever experienced any kind of seizure, please consult your doctor before viewing 3D images. If you experience one of the following symptoms while watching a 3D video, stop watching the 3D video immediately and take a rest.
- Dizziness, twitching of the eye or facial muscles, involuntary movements, cramp, loss of consciousness, confusion, loss of sense of direction, or nausea. If the symptom does not disappear, please consult your doctor.
- You can reduce the risk of photosensitive seizures by taking the following preventive measures.
 - Take a rest of 5 15 mins. for every 1 hour of viewing.
 - If vision varies between each eye, correct the variation before beginning to watch a 3D video.
 - Ensure that the 3D video is directly in front of you, at eye level.
 - You should stop watching if you experience a headache, fatigue or dizziness.
 - Do not view 3D images when you are tired or ill.

A CAUTION

 Extra special care is required for children watching a 3D video.

When Watching 3D Video


- Watch 3D images within the optimum viewing angle and distance.
- If you are outside the viewing angle or distance, you may not be able to watch 3D images. You cannot view 3D images when you lie down.
- You may see left and right images overlapped during projector initialization after it is powered on. It may take some time for optimization.
- It may take some time for the 3D image look normal after you turn your eyes away from the screen and look back at the 3D image.
- It may flicker slightly while watching 3D images under a 3 wavelength lamp fluorescent light (50 Hz - 60 Hz) or near windows. If so, it is recommended to block the sun light with a curtain and to dim the lights.
- The 3D glasses must be DLP-LINK (DLP Ready) type.
- You may not be able to watch 3D properly if there is an obstacle between the projector and 3D glasses.
- Install the 3D projector as far as possible from other devices.

Please check the following when using

3D glasses.

- Do not use 3D glasses as ordinary glasses, sunglasses or protective goggles.
 - If you do so, this may cause injury.
- Do not store 3D glasses in very hot or very cold conditions. If you do, this may cause them to become distorted. Do not use distorted glasses.
- Do not drop 3D glasses or allow them to come into contact with other objects.
 - This can result in damage to the product.
- The lenses of 3D glasses are easily scratched. Use a soft clean cloth when cleaning them.
 - Foreign particles on the cloth may cause scratches.
- Do not scratch the surface of the 3D glasses' lenses with sharp objects or wipe them with chemicals.
 - If the lenses get scratched, images may not look normal when viewing 3D.
- Please use 3D glasses certified by LG Electronics.

Requirements for Watching 3D Images



- * Basically, Watching 3D videos should be done in dark room environments only.
- * For 3D watching, set the energy saving mode to Minimum.



NOTE

- The pairing with the DLP-LINK glasses is affected by the intensity of light reflected from the screen.
 Therefore, the pairing with DLP-LINK glasses may not work properly if the light reflected from the screen is not bright enough, such as when the surrounding area is bright, the screen is big, or the maximum energy saving mode is enabled.
- Some menus may not work while playing a 3D video.
- You can only watch a 3D video properly when the 3D video format option has been selected on the projector.

1 Please check the minimum system requirements for your computer. Minimum requirements are as follows:

Microsoft® Windows® XP, Vista 32/64bit ,Windows 7 32/64bit Intel® Core 2 Duo or AMD Athlon™ X2 CPU or higher More than 1 GB of system memory (2 GB recommended) Free space of 100 MB or more DirectX 9 or higher Video card should support 120 vertical frequency (Hz).

- Recommended video card requirements
 - Graphic Processor speed 700MHz higher
 - Memory 512MB higher
- · A laptop equipped with the chipsets above can be used but it may not work properly.
- **2** Set the video output to XGA 120 Hz and play a video file using a video player that supports 3D output.

The following video players support 3D output: Stereoscopic Player, nVidia 3D Vision, and TriDef 3D.

For more information on the players above, please visit their websites at:

www.3dtv.com

www.nvidia.co.kr

www.tridef.com

To Use DLP-LINK (DLP-Ready) Type Glasses

- 1 While watching 3D images from the projector, press buttons on the glasses.
- **2** When you press the button, the glasses flicker to be synchronized with the 3D images.
 - (The flickering is a unique operation method of DLP-LINK type glasses. It may be different depending on the glasses type.)
- 3 If the glasses flicker or problems occur while watching 3D, first turn the lights off to make the room darker. Contact your projector seller for queries about the glasses.

Supported 3D input formats

Input	Signal	Resolution	Vertical Frequency (Hz)	Supported 3D Formats
HDMI	XGA	1024×768	120	Frame Sequential / Frame Alternative
RGB-PC	XGA	1024×768	120	Frame Sequential / Frame Alternative

- The resolution supporting 3D mode is 1024x768 for HDMI and RGB input.
- Some menus may not work in 120Hz input.

Watching 3D Images

- 1 Play supported 3D video titles.
- **2** For RGB-PC, you must press **"AUTO"** on the remote control before watching 3D.
- **3** Press the **3D** button.
- 4 While watching 3D images from the projector, press buttons on the glasses.
- 5 Press the L/R button to switch the playing direction of an image. Select a screen with better 3D display quality.
- If you press the **3D** button during viewing, it returns to 2D.
- 6 If a 2D image is displayed on the 16:9 screen, a 3D image is also displayed at the aspect ratio of 16:9. For ratios other than 16:9, a 3D image is displayed in 4:3.
- You cannot change the screen size for 3D images.

CUSTOMIZING SETTINGS

SETUP Menu

- 1 Press the **SETTINGS** button.
- ${f 2}$ Use the ${f \wedge}, {f \vee}, {f <}$ or ${f >}$ button to select a desired item and press the ${f OK}$ button.
- $\bf 3$ Use the \land , \lor , < or > button to set up a desired item and press the $\bf OK$ button.
- 4 When you finished, press EXIT.

	Menu	Description
	PICTURE	Adjusts the image quality for optimal viewing.
	AUDIO	Adjusts the sound quality and volume level.
	TIME	Time-related features.
X	OPTION	Customizes the general settings.
	INPUT	Selects the desired input source.
	MY MEDIA	Accesses photo, music, movie, and document files.

PICTURE Settings

- 1 Press the **SETTINGS** button.
- **2** Use the \land , \lor , \lt or \gt button to select **PICTURE** and press the **OK** button.
- **3** Use the \land , \lor , \lt or \gt button to set up a desired item and press the **OK** button.
 - To return to the previous menu, press the 5 button.
- 4 When you finished, press EXIT.



The available picture settings are described as follows.

Setting	Description		
Energy Saving	Reduces the power consumption by adjusting the screen brightness.		
Picture	Selects one	e of the preset images or customizes options in each mode	
Mode	for the best	screen performance.	
	You are also	able to customize advanced options of each mode.	
	Mode		
	Vivid	Maximizes the visual effect of video. Displays a crystal clear picture by enhancing contrast, brightness, and sharpness.	
	Standard	Displays the picture in normal contrast, brightness and sharpness.	
	Cinema	Optimizes the image for movie.	
	Sport	Optimizes the image for sports by emphasizing primary colors and dynamic actions.	
	GAME Optimizes the image for playing games on fast-moving screens.		
	Expert	Adjusts the detailed image settings.	
CON- TRAST	Increases or decreases the gradient of the video signal.		
BRIGHT- NESS	Adjusts the base level of the video signal to make the image brighter or darker.		
Sharpness	Adjusts the level of sharpness in the edge between the light and dark areas of the picture. The lower the level is, the softer the image looks.		
Color	Adjusts the intensity of all colors.		
Tint	Adjusts the balance between red and green levels.		
Advanced	Customizes	the advanced settings.	
Control			

Setting	Description		
Picture	Restores th	e options of each mode to the factory default.	
Reset			
Aspect	Changed th	ne image size to view images at its optimal size. (see page20)	
Ratio			
Picture	By following	the instructions, using the remote control, you can eas-	
Wizard II	ily adjust th	e picture quality to technical standards without needing an	
	expensive p	pattern device or a picture quality expert.	
Screen	Adjusts the	picture quality of RGB-PC input.	
(RGB-PC)	Option		
	Resolution	Available resolutions are 768 resolution	
		(1024x768/1280x768/1360x768, 60Hz) and 1050 resolu-	
	tion (1400x1050/1680x1050, 60Hz).		
	Auto	Provides optimized picture quality by automatically calibrat-	
	Config.	ing the mismatch of horizontal width and picture shake	
		caused by clashes between the internal settings of the pro-	
	jector and various PC graphic signals.		
	You can also use the AUTO button on the remote control.		
	Position Moves the image up/down/left/right.		
	Size	Changes the screen size.	
	Phase	Makes the picture look clear by removing horizontal noise.	
	Reset	Restores all the settings to the factory default.	

Advanced Control

Setting	Description
Dynamic Con-	Adjusts the contrast to keep it at the best level according to the
trast	brightness of the screen.
Dynamic Color	Adjusts screen colors so that they look natural.
Clear White	Makes the white area of screen look brighter and whiter.
Skin Color	Detects the skin area of image and adjusts it to render a natural skin
	color.
Noise Reduc-	Reduces image noise.
tion	
Digital Noise	This option reduces the noise produced while creating digital video
Reduction	signals.
GAMMA	Sets a gradation curve between video input and output signal.
Black Level	Compensates the brightness and contrast of a screen to balance
	with the black level of the video input.
	Not available for RGB-PC.
Real Cinema	Provides the optimal picture quality for watching a movie.
Color Gamut	Selects the range of colors to display. Standard: Displays the original colors of an input signal regardless of the display features. Wide: Sets to use the rich colors of the display.
Edge	Provides much sharper and clearer edges to the picture.
Enhancer	
Color Filter	Accurately adjusts color and tint by filtering a specific color area of
	RGB space.
White Peaking	Adjust white color brightness. White peaking can be adjusted from 0
	to 10. Adjust to higher setting to achieve brighter picture. Adjust to
	lower setting for darker picture.

Setting	Description	
Color Tem-	Adjusts the overall color of the screen to suit your preference.	
perature	Select Warm, Cool or Medium.	
	In Expert mode, you can customize the options of each mode.	
	Gamma : Select 1.9 , 2.2 ,or 2.4 .	
	a. Method: 2 points	
	- Pattern: Inner, Outer	
	- Contrast Red/Green/Blue, Brightness Red/Green/Blue:	
	Adjustable range -50 - +50.	
	b. Method: 10 points IRE	
	- Pattern: Inner, Outer	
	- IRE (Institute of Radio Engineers) is the unit that indicates the	
	size of the video signal and can be set as either 10, 20, 30 - 90,	
	or 100. You can fine-tune for each setting as shown below.	
	- Luminance: If you set up luminance for 100 IRE, a luminance	
	value satisfying each gamma is automatically calcu-	
	lated for each step from 10 IRE to 90 IRE.	
6 1 14	- Red/Green/Blue: The adjustment range is -50 - +50.	
Color Manage-	Adjusts Red/Green/Blue/Yellow/Cyan/Magenta colors. Allows an	
ment	expert to adjust the tint using a test pattern. Six colors (Red/Green/	
	Blue/Cyan/Magenta/Yellow) can be selectively adjusted without af-	
	fecting other colors.	
	You may not see colors change on a normal picture even after ad-	
	justment.	
	- Chroma Red/Green/Blue/Yellow/Cyan/Magenta,	
	Tone Red/Green/Blue/Yellow/Cyan, Magenta:	
	The adjustment range is -30 - +30 each.	

AUDIO Settings

- 1 Press the **SETTINGS** button.
- **2** Use the \land , \lor , \lt , \gt buttons to select **AUDIO** and press the **OK** button.
- **3** Use the \land , \lor , \lt or \gt button to set up a desired item and press the **OK** button.
 - To return to the previous menu, press the 5 button.
- 4 When you finished, press EXIT.



The available audio settings are described as follows.

Setting		Description
Auto Volume	Automatically adjusts the volume level.	
Clear Voice II	Makes the voice from the projector crisp and clear.	
Balance	Adjusts the bala	ance of the left and right speakers.
Sound Mode	Adjusts sound.	
	Option	
	Standard	Select when you want standard-quality sound.
	Music	Select when you listen to music.
	Cinema	Select when you watch movies.
	Sport	Select when you watch sports events.
	Game	Select when you play games.
Infinite	LG's unique sound option provides 5.1 channel stereo sound from	
Surround	two speakers.	
Treble	Adjusts the treble sound.	
Bass	Adjusts the base sound.	
RESET	Resets all the sound settings to the factory default.	

TIME Settings

- 1 Press the **SETTINGS** button.
- **2** Use the \land , \lor , \lt or \gt button to select **TIME** and press the **OK** button.
- **3** Use the \land , \lor , \lt or \gt button to set up a desired item and press the **OK** button.
 - To return to the previous menu, press the 5
- 4 When you finished, press EXIT.



The available time settings are described as follows.

Setting	Description
Sleep	The projector is turned off at the preset time.
Timer	
Auto Off	If there is no signal, the projector automatically turns off after the preset
	time has elapsed.
Automatic	If you do not press any button when Automatic Standby function is on,
Standby	the Projector automatically switches to the standby mode.

OPTION Settings

- 1 Press the **SETTINGS** button.
- **2** Use the \land , \lor , \lt or \gt button to select **OPTION** and press the **OK** button.
- **3** Use the \land , \lor , \lt or \gt button to set up a desired item and press the **OK** button.
 - To return to the previous menu, press the $\ \ \ \$ button.
- 4 When you finished, press EXIT.




The available option settings are described as follows.

Setting		Description	
Language	Selects a desired Menu Language.		
PJT	This funct	ion turns the projected image upside down or flips horizontal.	
Mode	• Select	Rear when projecting from the back of the transparent screen	
	purcha	sed separately.	
	 Select 	Ceiling when installing the product on the ceiling.	
	• When I	PJT Mode is Rear/Front Ceiling, the left/right of the speaker	
	change	es automatically.	
Auto	Auto Keys	tone provides a rectangular screen image by automatically	
Keystone	adjusting the Keystone number when there is a trapezoidal screen image		
	caused by	tilting of the projector.	
	Option		
	ON	ON Automatically adjusts the Keystone number.	
	Off	Manually adjusts the Keystone number.	
Keystone	To prevent the screen image from becoming trapezoidal, Keystone adjusts		
	the top an	nd bottom width of the image if the projector is not set at a right	
	angle to th	ne screen.	
Blank	Selects a background for blank Image. (see page22)		
Image			
3D Mode	Selects 3D mode.		
Auto	Automatically searches and displays an input signal type when it is re-		
Input	ceived.		
Search			

Setting		Description
Auto Power	Makes the projector turn on automatically when the adaptor plug is inserted.	
	Option	
	On	When the DC plug is connected to the projector, it turns on automatically.
	Off	When the DC plug is connected to the projector, it goes into standby mode.
High	If the proje	ector is used at an altitude higher than 1200 meters, turn this
Altitude	on.	
	Otherwise, the projector may overheat or its protection function may be	
	activated. If this happens, turn the projector off and then on again after waiting for several minutes.	
Caption	If the language for the AV input is set to Korean, captions can be turned	
	on or off.	
DivX(R)	sets DivX related settings.	
VOD		
Initial	Resets all the projector settings to the factory default.	
Setting		

MAKING CONNECTIONS

You can connect various external devices to the ports on the projector.




Connecting to an HD Receiver, DVD, or VCR Player

Connect an HD receiver, DVD, or VCR player to the projector and select an appropriate input mode.

HDMI Connection

With an HDMI cable, you can enjoy high quality picture and sound. Press the **INPUT** button on the remote control to select **HDMI**.




Connecting to a PC


The projector supports Plug & Play. A PC will automatically recognize the projector and requires no driver to be installed.

RGB Connection

Connect the PC output and the PC video input port of the projector with the RGB cable.

For audio signal, connect the PC and the projector with an optional audio cable.






You can connect the audio cable without using a gender as shown in the illustration above.


Connecting to the AV INPUT

Connect the output ports of an external device and the AV INPUT port of the projector. Press the **INPUT** button to select **AV**.




Component Connection

You can enjoy vivid images when you connect an external device with a **RGB IN** port to the component port of the projector. Press the **INPUT** button on the remote control to select **Component**.



Connecting to Headphones

You can listen to the audio through a headphone.



MAINTENANCE

Clean your projector to keep it in optimum condition.

Cleaning the Projector

Cleaning the Lens

If there is any dust or staining on the lens surface, you must clean the lens. Use an air spray or a cleaning cloth to clean the lens.

To remove dust or stains, use an air spray or apply a small amount of cleaning agent onto a swab or soft cloth to lightly rub the lens.

Please be aware that liquid may flow onto the lens if the product is sprayed directly onto the lens.

Cleaning the Projector Case


To clean the projector case, first unplug the power cord.

To remove dust or stains, use only a dry, lint-free, nonabrasive cloth to polish the lens.


Do not use alcohol, benzene, thinners or other chemicals, which may damage the case

How to Fix the Lens Cap

- Prepare the lens cap and the strap supplied as accessories.
- 2 Insert the end of the strap into the hole at the bottom of the lens section of the projector. Fix the strap to the projector by inserting and pulling the other end of the strap into the other end.



3 Insert the other end of strap into the hole of the lens cap, and then pass the lens cap through the strap.



SPECIFICATIONS

MODELS	PA70G (PA70G-JE)				
Resolution (Pixel)	1280 (Horizontal) × 800 (Vertical)				
Aspect ratio	16:10 (Horizontal:Vertical)				
Panel size (mm)	11.623				
Projection distance	0.00 2.07 777 2 2540 1				
(Video size)	0.90 m - 3.06 m (76.2 cm - 254.0 cm)				
Ratio of upward	100 %				
projection	100 %				
Working range of the	6 m				
remote control					
Video input	NTSC M / PAL-B, D, G, H, I / PAL M / PAL N / PAL 60 / SECAM				
AC-DC Adaptor	19.5 V, 7.18 A				
Audio Output	3W + 3W				
Height (mm)	Front Side	56.5 (without foot), 60.0 (with foot)			
	Rear Side	44.0 (without foot), 47.5 (with foot)			
Width (mm)	230.0				
Depth (mm)	170.0				
Weight (g)	1350				
USB Device	5 V, 0.5 A (Max.)				
	Temperature				
	Operation	0°C - 40°C			
Operation	Storage -20°C - 60°C				
environment	Relative Humidity				
	Operation 0 % - 80%				
	Storage	0 % - 85%			

Supported Monitor Display

	Horizontal	Vertical
Resolution	Frequency	Frequency
	(kHz)	(Hz)
640*350	31.468	70.09
720*400	31.469 70.08	
640*480	31.469	59.94
800*600	37.879	60.31
1024*768	48.363	60.00
1024 766		119.99
1152*864	54.348	60.053
1280*800	49.68	60
1360*768	47.712	60.015
1280*1024	63.981	60.020
1400*1050	65.317	59.979
1680*1050	65.3	60

- If an invalid signal is input into the projector, it will not be displayed properly on the screen or a message such as "No Signal" or "Invalid Mode" will be displayed.
- The projector supports the DDC1/2B type as the Plug & Play function (Auto-recognition of PC monitor).
- PC synchronization signal types supported: Separate type synchronization.
- In PC mode, 1280x800 is recommended for the best picture quality.

HDMI/DVI-DTV supported mode

	Horizontal	Vertical
Resolution	Frequency	Frequency
	(kHz)	(Hz)
720*480	31.469	59.94
	31.5	60
720*576	31.25	50
1280*720	37.5	50
	44.96	59.94
	45	60
1920*1080	33.72	59.94
	33.75	60
	28.125	50
	26.97	23.97
	27	24
	33.716	29.976
	33.75	30.00
	56.25	50
	67.43	59.94
	67.5	60

Component port connecting information

Signal	Component	
480i / 576i	0	
480p / 576p	0	
720p / 1080i	0	
1080p	o (50 Hz / 60 Hz only)	

Open Source Software Information

To obtain the source code under the GPL, LGPL, MPL and other open source licenses, which is contained in this product, please visit

http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

If you send an email to opensource@lge. com to request for the software's open source code installed into the projector within three years of purchase, we will send you a CD-ROM. You will only be charged a minimum for packaging and delivery.



The model and serial number of the projector are located on the back or on the side of the projector. Record them below should you ever need service.

MODEL		
SERIAL		